

Description	Material	Finish
Body	Brass	Gold
Socket	BE CU	Gold
Insulation	PTFE	N/A
Crimp Ring	Brass	Gold
Heat Shrink	Polyolefin	Black

	REVISIONS							
REV	DESCRIPTION	DATE	APPV					
В	Added new title block and heat shrink; updated instructions	11-JUL-12	SAH					


SIDE VIEW




SOCKET



## **CRIMP RING**





NOTES: (UNLESS OTHERWISE SPECIFIED)

- 1. ALL DIMENSIONS ARE IN INCHES [mm].
- 2. DIMENSIONS APPLY AFTER FINISHING.
- 3. MANUFACTURE TO BE COMPLIANT WITH EU ROHS DIRECTIVE.
- 4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.

RG-174 Cable	WARNING : THIS DRAWING CONTAINS PROPRIETARY INFORMATION THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS DESIGNATED AGENTS.		TITLE:	159 ORT LA MERLIN, OR S				
		TOLERANCES: .020 [0.50]200 [5.00]= ±.008 [0. .200 [5.00]-1.200 [30.00]= ±.016	$[0.40]$ $- + (\oplus)$	0175		FOR RG174 CABLE		
		1.20 [30.0]-4.75 [120.0]= ±.024 [0 4.75 [120.0]-12.40 [315.0]= ±.040	D.60] D.[1.0] ANGLES: +1°	SIZE	DWG. N	0.		REV
	FINISH:		DT: 11-JUL-12	Α		CONMCX011		В
		ENGR: S.HOGAN	DT: 11-JUL-12	SCALE	: 2:1	DO NOT SCALE DRAWING	SHEET 1	OF 1

## CONMCX011 ASSEMBLY INSTRUCTIONS

- 1. Strip cable to recommended dimensions.
- Slip heat shrink and crimp ring onto stripped cable. 2.
- Solder the socket to the center conductor. 3.
- Insert the socket, center conductor, and insulator into the body 4. until the top of the socket is even with the white insulation in the body.
- 5. Wrap the braid around the tail of the body and crimp the ring with a 0.128" hex crimp tool (or one labeled for use with RG-174 cable).
- Use heat shrink to cover crimp. 6.

0.079 0.102

(2.00) (2.60)

## **RECOMMENDED CABLE STRIPPING DIMENSIONS** 0.189

(4.80)