

The Future of Analog IC Technology

# DESCRIPTION

The MP2364 is a dual monolithic step-down switch mode converter with built-in internal power MOSFETs. It achieves 1.5A continuous output current for each output over a wide input supply range with excellent load and line regulation.

Current mode operation provides fast transient response and eases loop stabilization.

Fault condition protection includes cycle-by-cycle current limiting and thermal shutdown. In shutdown mode, the regulator draws 40µA of supply current.

The MP2364 requires a minimum number of readily available standard external components.

### **EVALUATION BOARD REFERENCE**

Board Number	Dimensions
EV2364DF-01A	2.2"X x 1.6"Y x 0.4"Z

## **FEATURES**

- 1.5A Current for Each Output
- 0.18Ω Internal Power MOSFET Switches
- Stable with Low ESR Output Ceramic Capacitors
- Up to 90% Efficiency
- 40µA Shutdown Mode
- Fixed 1.4MHz Frequency
- Thermal Shutdown
- Cycle-by-Cycle Over Current Protection
- Wide 4.75V to 23V Operating Input Range
- Each Output Adjustable from 0.92V to 16V
- Configurable for Single Output with Double the Current
- Programmable Under Voltage Lockout
- Programmable Soft-Start
- Available in TSSOP20 with Exposed Pad and SOIC Packages

### **APPLICATIONS**

- Distributed Power Systems
- I/O and Core supplies
- DSL Modems
- Set top boxes
- Cable Modems

"MPS" and "The Future of Analog IC Technology" are Trademarks of Monolithic Power Systems, Inc.



www.MonolithicPower.com MPS Proprietary Information. Unauthorized Photocopy and Duplication Prohibited. © 2006 MPS. All Rights Reserved.



<u>旦问 WF2304 供应同</u>

# PACKAGE REFERENCE



For Tape & Reel, add suffix –Z (eg. MP2364DF–Z)
For Lead Free, add suffix –LF (eg. MP2364DF–LF–Z)

## ABSOLUTE MAXIMUM RATINGS (1)

Supply Voltage (INA, INB)	25V
Switch Voltage (SWA, SWB)	26V
Bootstrap Voltage (BSA, BSB)	V <sub>SW</sub> + 6V
Feedback Voltage (FBA, FBB)	–0.3V to +6V
Enable/UVLO Voltage (ENA, ENB)	–0.3V to +6V
Comp Voltage (COMPA, COMPB)	–0.3V to +6V
Soft Start Voltage (SSA, SSB)	–0.3V to +6V
Junction Temperature	+150°C
Lead Temperature	+260°C
Storage Temperature	65°C to +150°C

	TOP VIEW	
SSA 1	•	16 ENA
BSA 2		15 COMPA
INA 3		14 FBA
SWA 4		13 GNDB
GNDA 5		12 SWB
FBB 6		11 INB
COMPB 7		10 BSB
ENB 8		9 SSB
		MP2364_PD02_SOIC16
Part Number*	Package	Temperature
MP2364DS	SOIC16	-40°C to +85°C

\* For Tape & Reel, add suffix –Z (eg. MP2364DS–Z) For Lead Free, add suffix –LF (eg. MP2364DS–LF–Z)

# Recommended Operating Conditions <sup>(2)</sup>

Supply Voltage (VIN)	4.75V to 23V
Operating Temperature	.–40°C to +85°C

Thermal Resistance <sup>(3)</sup>	$\boldsymbol{\theta}_{JA}$	$\boldsymbol{\theta}_{JC}$	
TSSOP20F	40	6	°C/W
SOIC16	105	40	°C/W

#### Notes:

1) Exceeding these ratings may damage the device.

 The device is not guaranteed to function outside of its operating conditions.

3) Measured on approximately 1" square of 1 oz copper.



## **ELECTRICAL CHARACTERISTICS**

 $V_{IN} = 12V$ ,  $T_A = +25^{\circ}C$ , unless otherwise noted.

Parameter	Symbol	Condition	Min	Тур	Max	Units
Feedback Voltage	$V_{\text{FB}}$	$4.75V \le V_{\text{IN}} \le 23V$	0.892	0.920	0.948	V
Upper Switch-On Resistance	R <sub>DS(ON)1</sub>			0.18		Ω
Lower Switch-On Resistance	R <sub>DS(ON)2</sub>			10		Ω
Upper Switch Leakage		$V_{EN}$ = 0V, $V_{SW}$ = 0V			10	μA
Current Limit <sup>(4)</sup>			2.5	3.0		А
Current Limit Gain Output Current to Comp Pin Voltage	G <sub>CS</sub>			1.95		A/V
Error Amplifier Voltage Gain	A <sub>VEA</sub>			400		V/V
Error Amplifier Transconductance	$G_{EA}$	$\Delta I_{C} = \pm 10 \ \mu A$	630	930	1230	µA/V
Oscillator Frequency	f <sub>OSC</sub>			1.4		MHz
Short Circuit Frequency	f <sub>SC</sub>	V <sub>FB</sub> = 0V		210		KHz
Soft-Start Pin Equivalent Output Resistance				9		kΩ
EN Shutdown Threshold Voltage	$V_{\text{EN}}$	I <sub>CC</sub> > 100μΑ	0.7	1.0	1.3	V
Enable Pull-Up Current	I <sub>EN</sub>			1.0		μA
EN UVLO Threshold Rising	V <sub>UVLO</sub>	V <sub>EN</sub> Rising	2.37	2.50	2.62	V
EN UVLO Threshold Hysteresis				210		mV
Supply Current (Shutdown)	I <sub>OFF</sub>	$V_{EN} \le 0.4 V$		40	70	μA
Supply Current (Quiescent)	I <sub>ON</sub>	$V_{EN} \ge 3V$		2.4	2.8	mA
Thermal Shutdown	D <sub>MAX</sub>			160		°C
Maximum Duty Cycle		V <sub>FB</sub> = 0.8V		70		%
Minimum On Time	t <sub>ON</sub>			100		ns

Note:

4) Equivalent output current = 1.5A ≥ 50% Duty Cycle 2.0A ≤ 50% Duty Cycle Assumes ripple current = 30% of load current. Slope compensation changes current limit above 40% duty cycle.



# **PIN FUNCTIONS (TSSOP20F)**

Pin #	Name	Description		
1	SSA	Soft-Start Control for Channel A. $9k\Omega$ output resistance from the pin. Set RC time constant with external capacitor for soft start ramp time. Ramp Time = $2.2 \times 9k\Omega \times C$ .		
2	NC	No Connect		
3	BSA	High-Side Driver Boost Pin. Connect a 10nF capacitor from this pin to SWA.		
4	INA	Supply Voltage Channel A. The MP2364 operates from a +4.75V to +23V unregulated input. Input Ceramic Capacitors should be close to this pin.		
5	SWA	Switch Channel A. This connects the inductor to either INA through M1A or to PGA through M2A.		
6	PGA	Power Ground Channel A. This is the Power Ground Connection to the input capacitor ground.		
7	SGA	Signal Ground Channel A. This pin is the signal ground reference for the regulated output voltage. For this reason care must be taken in its layout. This node should be placed outside of the D1 to C1 ground path to prevent switching current spikes from inducing voltage noise into the part.		
8	FBB	Feedback Voltage for Channel B. This pin is the feedback voltage. The output voltage is ratio scaled through a voltage divider, and the center point of the divider is connected to this pin. The voltage is compared to the on board 0.92V reference.		
9	COMPB	Compensation Channel B. This is the output of the transconductance error amplifier. A series RC is placed on this pin for proper control loop compensation. Please refer to more in the datasheet.		
10	ENB	Enable/UVLO Channel B. A voltage greater than 2.62V enables operation. Leave ENB unconnected for automatic startup. An Under Voltage Lockout (UVLO) function can be implemented by the addition of a resistor divider from $V_{IN}$ to GND. For complete low current shutdown the ENB pin voltage needs to be less than 700mV.		
11	SSB	Soft-Start Control for Channel B. $9k\Omega$ output resistance from the pin. Set RC time constant with external capacitor for soft start ramp time. Ramp Time = $2.2x9k\Omega xC$ .		
12	BSB	High-Side Driver Boost Pin. Connect a 10nF capacitor from this pin to SWB.		
13	NC	No Connect.		
14	INB	Supply Voltage Channel B. The MP2364 operates from a +4.75V to +23V unregulated input. Input Ceramic Capacitors should be close to this pin.		
15	SWB	Switch Channel B. This connects the inductor to either INB through M1B or to PGB through M2B.		
16	PGB	Power Ground Channel B. This is the Power Ground Connection to the input capacitor ground.		
17	SGB	Signal Ground Channel B. This pin is the signal ground reference for the regulated output voltage. For this reason care must be taken in its layout. This node should be placed outside of the D1 to C1 ground path to prevent switching current spikes from inducing voltage noise into the part.		
18	FBA	Feedback Voltage for Channel A. This pin is the feedback voltage. The output voltage is ratio scaled through a voltage divider, and the center point of the divider is connected to this pin. The voltage is compared to the on board 0.92V reference.		
19	COMPA	Compensation Channel A. This is the output of the transconductance error amplifier. A series RC is placed on this pin for proper control loop compensation. Please refer to more in the datasheet.		
20	ENA	Enable/UVLO Channel A. A voltage greater than 2.62V enables operation. Leave ENA unconnected for automatic startup. An Under Voltage Lockout (UVLO) function can be implemented by the addition of a resistor divider from $V_{IN}$ to GND. For complete low current shutdown the ENA pin voltage needs to be less than 700mV.		



# **PIN FUNCTIONS (SOIC16)**

Pin #	Name	Description
1	SSA	Soft-Start Control for Channel A. $9k\Omega$ output resistance from the pin. Set RC time constant with external capacitor for soft start ramp time. Ramp Time = $2.2 \times 9k\Omega \times C$ .
2	BSA	High-Side Driver Boost Pin. Connect a 10nF capacitor from this pin to SWA.
3	INA	Supply Voltage Channel A. The MP2364 operates from a +4.75V to +23V unregulated input. Input Ceramic Capacitors should be close to this pin.
4	SWA	Switch Channel A. This connects the inductor to either INA through M1A or to PGA through M2A.
5	GNDA	Ground A.
6	FBB	Feedback Voltage for Channel B. This pin is the feedback voltage. The output voltage is ratio scaled through a voltage divider, and the center point of the divider is connected to this pin. The voltage is compared to the on board 0.92V reference.
7	СОМРВ	Compensation Channel B. This is the output of the transconductance error amplifier. A series RC is placed on this pin for proper control loop compensation. Please refer to more in the datasheet.
8	ENB	Enable/UVLO Channel B. A voltage greater than 2.62V enables operation. Leave ENB unconnected for automatic startup. An Under Voltage Lockout (UVLO) function can be implemented by the addition of a resistor divider from $V_{IN}$ to GND. For complete low current shutdown the ENB pin voltage needs to be less than 700mV.
9	SSB	Soft-Start Control for Channel B. $9k\Omega$ output resistance from the pin. Set RC time constant with external capacitor for soft start ramp time. Ramp Time = $2.2x9k\Omega xC$ .
10	BSB	High-Side Driver Boost Pin. Connect a 10nF capacitor from this pin to SWB.
11	INB	Supply Voltage Channel B. The MP2364 operates from a +4.75V to +23V unregulated input. Input Ceramic Capacitors should be close to this pin.
12	SWB	Switch Channel B. This connects the inductor to either INB through M1B or to PGB through M2B.
13	GNDB	Ground B.
14	FBA	Feedback Voltage for Channel A. This pin is the feedback voltage. The output voltage is ratio scaled through a voltage divider, and the center point of the divider is connected to this pin. The voltage is compared to the on board 0.92V reference.
15	COMPA	Compensation Channel A. This is the output of the transconductance error amplifier. A series RC is placed on this pin for proper control loop compensation. Please refer to more in the datasheet.
16	ENA	Enable/UVLO Channel A. A voltage greater than 2.62V enables operation. Leave ENA unconnected for automatic startup. An Under Voltage Lockout (UVLO) function can be implemented by the addition of a resistor divider from $V_{IN}$ to GND. For complete low current shutdown the ENA pin voltage needs to be less than 700mV.



### **OPERATION**

The MP2364 is a dual channel current mode regulator. The COMP pin voltage is proportional to the peak inductor current. At the beginning of a cycle, the upper transistor M1 is off, and the lower transistor M2 is on (see Figure 1). The COMP pin voltage is higher than the current sense amplifier output, and the current comparator's output is low. The rising edge of the 1.4MHz CLK signal sets the RS Flip-Flop. Its output turns off M2 and turns on M1 thus connecting the SW pin and inductor to the input supply. The increasing inductor current is sensed and amplified by the Current Sense Amplifier. Ramp compensation is summed to Current Sense Amplifier output and compared to the Error Amplifier output by the Current Comparator.

When the sum of the Current Sense Amplifier output and the Slope Compensation signal exceeds the COMP pin voltage, the RS Flip-Flop is reset. The MP2364 reverts to its initial M1 off, M2 on state. If the sum of the Current Sense Amplifier output and the Slope Compensation signal does not exceed the COMP voltage, the falling edge of the CLK resets the Flip-Flop.

The output of the Error Amplifier integrates the voltage difference between the feedback and the 0.92V bandgap reference. The polarity is such that a voltage at the FB pin lower than 0.92V increases the COMP pin voltage. Since the COMP pin voltage is proportional to the peak inductor current, an increase in its voltage increases current delivered to the output. The lower  $10\Omega$  switch ensures that the bootstrap capacitor voltage is charged during light load conditions. External Schottky Diode D1 carries the inductor current when M1 is off (see Figure 1).



(Diagram portrays <sup>1</sup>/<sub>2</sub> of the MP2364)



# APPLICATION INFORMATION COMPONENT SELECTION

The MP2364 has two channels: A and B. The following formulas are used for component selection of both channels. Refer to components with reference "A" for channel A, and components with reference "B" for channel B, respectively, as indicated in Figure 3 (i.e. – R1A for Channel A and R1B for Channel B).

#### Setting the Output Voltage

The output voltage is set using a resistive voltage divider from the output voltage to FB pin. The voltage divider divides the output voltage down to the feedback voltage by the ratio:

$$V_{FB} = V_{OUT} \frac{R2}{R1 + R2}$$

Thus the output voltage is:

$$V_{OUT} = 0.92V \times \frac{R1 + R2}{R2}$$

Where  $V_{\text{FB}}$  is the feedback voltage and  $V_{\text{OUT}}$  is the output voltage

A typical value for R2 can be as high as  $100k\Omega$ , but a typical value is  $10k\Omega$ . Using that value, R1 is determined by:

$$R1=R2\times(\frac{V_{OUT}}{0.92V}-1)$$

For example, for a 3.3V output voltage, R2 is  $10k\Omega$ , and R1 is  $25.9k\Omega$ .

### Inductor

The inductor is required to supply constant current to the output load while being driven by the switched input voltage. A larger value inductor will result in less ripple current that will result in lower output ripple voltage. However, the larger value inductor will have a larger physical size, higher series resistance, and/or lower saturation current. A good rule for determining the inductance to use is to allow the peak-to-peak ripple current in the inductor to be approximately 30% of the maximum switch current limit. Also, make sure that the peak inductor current is below the maximum switch current limit. The inductance value can be calculated by:

$$L1 = \frac{V_{OUT}}{f_S \times \Delta I_L} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

Where  $V_{IN}$  is the input voltage,  $f_S$  is the switching frequency, and  $\Delta I_L$  is the peak-to-peak inductor ripple current.

Choose an inductor that will not saturate under the maximum inductor peak current.

The peak inductor current can be calculated by:

$$I_{LP} = I_{LOAD} + \frac{V_{OUT}}{2 \times f_S \times L1} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

Where  $I_{LOAD}$  is the load current.

### **Output Rectifier Diode**

The output rectifier diode supplies the current to the inductor when the high-side switch is off. To reduce losses due to the diode forward voltage and recovery times, use a Schottky diode.

Choose a diode whose maximum reverse voltage rating is greater than the maximum input voltage, and whose current rating is greater than the maximum load current.

#### Input Capacitor

The input current to the step-down converter is discontinuous, therefore a capacitor is required to supply the AC current to the step-down converter while maintaining the DC input voltage. Use low ESR capacitors for the best performance. Ceramic capacitors are preferred, but tantalum or low-ESR electrolytic capacitors may also suffice.

Since the input capacitor (C1) absorbs the input switching current it requires an adequate ripple current rating. The RMS current in the input capacitor can be estimated by:

$$\mathbf{I_{C1}} = \mathbf{I_{LOAD}} \times \sqrt{\frac{\mathbf{V_{OUT}}}{\mathbf{V_{IN}}}} \times \left(1 - \frac{\mathbf{V_{OUT}}}{\mathbf{V_{IN}}}\right)$$

The worst-case condition occurs at  $V_{\text{IN}}$  =  $2V_{\text{OUT}},$  where:

$$I_{C1} = \frac{I_{LOAD}}{2}$$



For simplification, choose the input capacitor whose RMS current rating greater than half of the maximum load current.

The input capacitor can be electrolytic, tantalum or ceramic. When using electrolytic or tantalum capacitors, a small, high quality ceramic capacitor, i.e.  $0.1\mu$ F, should be placed as close to the IC as possible.

When using ceramic capacitors, make sure that they have enough capacitance to provide sufficient charge prevent excessive voltage ripple at input. The input voltage ripple caused by capacitance can be estimated by:

$$\Delta V_{IN} = \frac{I_{LOAD}}{C1} \times \frac{V_{OUT}}{V_{IN}} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

#### **Output Capacitor**

The output capacitor is required to maintain the DC output voltage. Ceramic, tantalum, or low ESR electrolytic capacitors are recommended. Low ESR capacitors are preferred to keep the output voltage ripple low. The output voltage ripple can be estimated by:

$$\Delta V_{OUT} = \frac{V_{OUT}}{f_{S} \times L1} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right) \times \left(R_{ESR} + \frac{1}{8 \times f_{S} \times C2}\right)$$

Where L1 is the inductor value, C2 is the output capacitance value, and  $R_{ESR}$  is the equivalent series resistance (ESR) value of the output capacitor.

In the case of ceramic capacitors, the impedance at the switching frequency is dominated by the capacitance. The output voltage ripple is mainly caused by the capacitance. For simplification, the output voltage ripple can be estimated by:

$$\Delta V_{OUT} = \frac{V_{OUT}}{8 \times f_{S}^{2} \times L1 \times C2} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right)$$

In the case of tantalum or electrolytic capacitors, the ESR dominates the impedance at the switching frequency. For simplification, the output ripple can be approximated to:

$$\Delta V_{OUT} = \frac{V_{OUT}}{f_{S} \times L1} \times \left(1 - \frac{V_{OUT}}{V_{IN}}\right) \times R_{ESR}$$

The characteristics of the output capacitor also affect the stability of the regulation system. The

MP2364 can be optimized for a wide range of capacitance and ESR values.

#### **Compensation Components**

The MP2364 employs current mode control on each channel for easy compensation and fast transient response. The system stability and transient response are controlled through the COMP pin. COMP pin is the output of the internal transconductance error amplifier. A series capacitor-resistor combination sets a pole-zero combination to control the characteristics of the control system.

The DC gain of the voltage feedback loop is given by:

$$A_{VDC} = R_{LOAD} \times G_{CS} \times A_{VEA} \times \frac{V_{FB}}{V_{OUT}}$$

Where  $A_{VEA}$  is the error amplifier voltage gain,  $G_{CS}$  is the current sense transconductance and  $R_{LOAD}$  is the load resistor value.

The system has two poles of importance. One is due to the compensation capacitor (C3) and the output resistor of error amplifier, and the other is due to the output capacitor and the load resistor. These poles are located at:

$$f_{P1} = \frac{G_{EA}}{2\pi \times C3 \times A_{VEA}}$$
$$f_{P2} = \frac{1}{2\pi \times C2 \times R_{LOAD}}$$

Where  $G_{\text{EA}}$  is the error amplifier transconductance.

The system has one zero of importance, due to the compensation capacitor (C3) and the compensation resistor (R3). This zero is located at:

$$f_{Z1} = \frac{1}{2\pi \times C3 \times R3}$$

The system may have another zero of importance, if the output capacitor has a large capacitance and/or a high ESR value. The zero, due to the ESR and capacitance of the output capacitor, is located at:

查询"MP2364"供应商

$$f_{ESR} = \frac{1}{2\pi \times C2 \times R_{ESR}}$$

In this case (as shown in Figure 2), a third pole set by the compensation capacitor (C6) and the compensation resistor (R3) is used to compensate the effect of the ESR zero on the loop gain. This pole is located at:

$$f_{P3} = \frac{1}{2\pi \times C6 \times R3}$$

The goal of compensation design is to shape the converter transfer function to get a desired loop gain. The system crossover frequency where the feedback loop has the unity gain is important.

Lower crossover frequencies result in slower line and load transient responses, while higher crossover frequencies could cause system unstable. A good rule of thumb is to set the crossover frequency to below one-tenth of the switching frequency. To optimize the compensation components for conditions not listed in Table 2, the following procedure can be used:

1. Choose the compensation resistor (R3) to set the desired crossover frequency. Determine the R3 value by the following equation:

$$R3 = \frac{2\pi \times C2 \times f_{C}}{G_{EA} \times G_{CS}} \times \frac{V_{OUT}}{V_{FB}}$$

Where  $f_C$  is the desired crossover frequency, which is typically less than one tenth of the switching frequency.

2. Choose the compensation capacitor (C3) to achieve the desired phase margin. For applications with typical inductor values, setting the compensation zero,  $f_{Z1}$ , to below one forth of the crossover frequency provides sufficient phase margin. Determine the C3 value by the following equation:

$$C3 > \frac{4}{2\pi \times R3 \times f_C}$$

Where R3 is the compensation resistor value.

3. Determine if the second compensation capacitor (C6) is required. It is required if the ESR zero of the output capacitor is located at less than half of the switching frequency, or the following relationship is valid:

$$\frac{1}{2\pi \times C2 \times R_{ESR}} < \frac{f_S}{2}$$

If this is the case, then add the second compensation capacitor (C6) to set the pole  $f_{P3}$  at the location of the ESR zero. Determine the C6 value by the equation:

$$C6 = \frac{C2 \times R_{ESR}}{R3}$$

#### Soft-Start

Each channel is soft-start controlled with the SSA and SSB pins. Use capacitors to control the ramp time using the equation:

 $RampTime = 2.2 \times 9 k\Omega \times C4$ 

#### **External Bootstrap Diode**

It is recommended that an external bootstrap diode be added when the system has a 5V fixed input or the power supply generates a 5V output. This helps improve the efficiency of the regulator. The bootstrap diode can be a low cost one such as IN4148 or BAT54.



### Figure 2—External Bootstrap Diode

This diode is also recommended for high duty cycle operation (when  $\frac{V_{OUT}}{V_{IN}}$  >65%) and high output voltage (V<sub>OUT</sub>>12V) applications.



### **TYPICAL APPLICATION CIRCUITS**



Figure 3—2.5V @ 1.5A and 3.3V @ 1.5A Application Circuit











SEE DETAIL "A"





DETAIL "B"

NOTE:

1) Control dimension is in inches. Dimension in bracket is millimeters.



SOIC16



#### NOTE:

- 1) CONTROL DIMENSION IS IN INCHES. DIMENSION IN BRACKET IS IN MILLIMETERS.
- 2) PACKAGE LENGTH AND WIDTH DO NOT INCLUDE MOLD FLASH, OR PROTRUSIONS.
- 3) DRAWING CONFORMS TO JEDEC MS-001, VARIATION BB.
- 4) DRAWING IS NOT TO SCALE.

**NOTICE:** The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.