# LM48821 Evaluation Board User's Guide

National Semiconductor Application Note 1589 Kevin Hoskins May 2007

# R

**Quick Start Guide** 

Connect the I<sup>2</sup>C signal generation and interface board to a computer's parallel port.

Install LM48821 control software: "LM48821\_Software." Amplifier output mode:

Apply a 2.0V to 4.0V power supply's positive voltage output to the "VDD" pin on jumper J6. Apply the power supply's ground return to the "GND" pin on J6.

Connect the supplied 5-wire cable between the I<sup>2</sup>C signal generation and interface board and the 5-pin connector (I2C Interface) on the LM48821 demonstration board.

Apply a stereo audio signal to jumpers JP2(Left) and JP3 (Right). Apply the source's +input and -input to the "+" pin and the "-" pin, respectively.

Connect a load ( $\geq 16\Omega$ ) to JP(Right) and another load to JP5 (Left). JP4's "+" pin and JP's "+" pin carries the output signals

from the two amplifiers found on pins OUTR and OUTL, respectively.

Apply power. Make measurements. Plug in a pair of headphones. Enjoy.

#### Introduction

To help the user investigate and evaluate the LM48821's performance and capabilities, a fully populated demonstration board is available from the National Semiconductor Corporation's Audio Products Group. This board is shown in Figure 1. Connected to an external power supply (2.0V to 4.0V), a signal source and an I<sup>2</sup>C controller (or signal source), the LM48821 demonstration board easily demonstrate the amplifier's features.

#### **General Description**

audio amplifier with an internal digitally controlled volume control. The LM48821 is optimized to operate over a power supply voltage range of 2.0V to 4.0V. This amplifier is capable of delivering 53mW\_{RMS} per channel into a 32 $\Omega$  load at 1% THD when powered by a 3.0V power supply.

Boomer audio power amplifiers were designed specifically to provide high quality output power with a minimal amount of external components. To that end, the LM48821 features two functions that optimize system cost and minimize PCB area: an integrated, digitally controlled (I<sup>2</sup>C bus) volume control and an amplifier generated negative power supply voltage that eliminates output signal-coupling capacitors. Since the LM48821 does not require bootstrap capacitors, snubber networks, or output coupling capacitors, it is optimally suited for low-power, battery powered potable systems.

The LM48821 includes separate shutdown controls for each stereo channel for micropower dissipation, an internal thermal shutdown protection mechanism, and is unity gain stable.

#### **Operating Conditions**

Temperature Range

 $-40^{\circ}C \le T_A \le 85^{\circ}C$ 

zsc.com

Amplifier Power Supply Voltage

 $2.0V \le V_{DD} \le 5.0V \le 4.0V$ SC.COM


#### **Board Features**

The LM48821 demonstration board has all of the necessary connections, using 0.100" headers, to apply the power supply voltage, the audio input signals, and the I<sup>2</sup>C signal inputs. The amplified audio signal is available on both a stereo headphone jack and auxiliary output connections.

Also included with the demonstration board is an I<sup>2</sup>C signal generation board and software. With this board and the software, the user can easily control the LM48821's, shutdown function, mute, and stereo volume control. Figure 3 shows the software's graphical user interface.

#### Schematic

Figure 2 shows the LM48821 Demonstration Board schematic. Refer to Table 3 for a list of the connections and their functions.



#### Connections

Connecting to the world is accomplished through the 0.100" headers on the LM48821 demonstration board. The functions of the different headers are detailed in Table 1.

#### TABLE 1. LM48821 Demonstration Board Connections

Jumper Designation	Function or Use
山市子市场	Stereo, 0.125" headphone jack. Left channel is on the tip connector and the right channel is on the ring connector. Ground is on the sleeve connector.
J2	This is the connection to the amplifier's differential left channel input. Apply an external differential signal source's positive voltage to the J2 pin labeled "L IN+" and the signal source's negative input to the pin labeled "L IN"
J3	This is the connection to the amplifier's differential right channel input. Apply an external differential signal source's positive voltage to the J3 pin labeled "R IN+" and the signal source's negative input to the pin labeled "R IN"
J4	This is the connection to the amplifier's single-ended, ground- referenced right channel output. Connect the J4 pin labeled "R OUT +" and the pin labeled "R OUT-" to the positive and ground inputs, respectively, of an external signal measurement device. J4's pin labeled "R OUT+" corresponds to the headphone jack's "ring" connection. J4's pin labeled "R OUT-" corresponds to the headphone jack's "sleeve" (or ground) connection.
J5	This is the connection to the amplifier's single-ended, ground- referenced left channel output. Connect the J5 pin labeled "L OUT+" and the pin labeled "L OUT-" to the positive and ground inputs, respectively, of an external signal measurement device. J5's pin labeled "L OUT+" corresponds to the headphone jack's "tip" connection. J5's pin labeled "L OUT-" corresponds to the headphone jack's "sleeve" (or ground) connection.
J6	Power supply connection. Connect an external power supply's positive voltage source (2.0V to 4.0V) to the J6 pin labeled "V <sub>DD</sub> " and the supply's ground source to the pin labeled "GND."
J8 (I <sup>2</sup> C Interface)	This is the input connection for the I <sup>2</sup> C serial clock and serial data signals. J8-pin 1 is for the SCL signal, JP8-pin 2 is not used. J8-pin 3 is for the SDA signal. J8-pin 4 is for an I <sup>2</sup> C V <sub>DD</sub> supply voltage supplied by the I <sup>2</sup> C signal source. J8-pin 5 is for ground.
JU1 WWW.DZSC	If an external I <sup>2</sup> C power supply voltage is used, connect this supply's positive voltage source to the JU1 pin labeled "I <sup>2</sup> CV <sub>DD</sub> " and the supply's ground source to the pin labeled "GND." If the external V <sub>DD</sub> power supply is used for the I <sup>2</sup> CV <sub>DD</sub> voltage, place a jumper between the JU1 pin labeled "V <sub>DD</sub> " and the JU1 pin labeled "I <sup>2</sup> CV <sub>DD</sub> ."



AN-1589



# **Power Supply Sequencing**

间LM48821任队员 The LM48821 uses wo power supply voltages: V<sub>DD</sub> for the analog circuitry and I2CV<sub>DD</sub>, which defines the digital control logic high voltage level. To ensure proper functionality, apply  $V_{\text{DD}}$  first, followed by  $I^2\text{CV}_{\text{DD}}.$  If one power supply is used,  $V_{DD}$  and I<sup>2</sup>CV<sub>DD</sub> can be connected together. The part will power-up with both channels shutdown, the volume control set to minimum, and the mute function active.

## I<sup>2</sup>C Signal Generation Board and Software

The I<sup>2</sup>C signal generation and interface board, along with the LM48821 software, will generate the address byte and the data byte used in the I<sup>2</sup>C control data transaction. To use the I<sup>2</sup>C signal generation and interface board, please plug it into a PC's parallel port (on either a notebook or a desktop computer).

The software comes with an installer. To install, unzip the file titled "LM48821\_Software." After the file unzips, double-click the "setup.exe" file. After it launches, please follow the installer's instructions. Setup will create a folder named "LM48821" in the "Program" folder on the "C" disk (if the default is used) along with a shortcut of the same name in the "Programs" folder in the "Start" menu.




Figure 3. The LM48821 Software User's Interface

The LM48821 program includes controls for the amplifier's volume control, individual channel shutdown, and the mute function. The control program's on-screen user interface is shown in Figure 3.

The Default button is used to return the LM48821 to its poweron reset state: minimum volume setting, shutdown on both amplifiers active, and mute active.

The LM48821's stereo VOLUME CONTROL has 32 steps and a gain range of -76dB to 18dB. It is controlled using the slider located at the bottom of the program's window. Each time the slider is moved from one tick mark to another, the program updates the amplifier's volume control.

LEFT CHANNEL, BOTH CHANNELS, and RIGHT CHAN-NEL controls each have two buttons. For the left and right channel control, the "ON" button activates its respective channel, whereas the "OFF" button places its respective channel in shutdown mode. Selecting the BOTH CHANNELS "ON" button simultaneously activates both channels, whereas selecting the "OFF" button places channels in shutdown mode.

## PCB Layout Guidelines

This section provides general practical guidelines for PCB layouts that use various power and ground traces. Designers should note that these are only "rule-of-thumb" recommendations and the actual results are predicated on the final layout.

#### POWER AND GROUND CIRCUITS

Star trace routing techniques (returning individual traces back to a central point rather than daisy chaining traces together in a serial manner) can have a major positive impact on low-level signal performance. Star trace routing refers to using individual traces that radiate from a signal point to feed power and ground to each circuit or even device. This technique may require greater design time, but should not increase the final price of the board.


For good THD+N and low noise performance and to ensure correct power-on behavior at the maximum allowed supply voltage, a local 4.7µF power supply bypass capacitor should be connected as physically close as possible to the  $PV_{DD}$  pin.

#### **AVOIDING TYPICAL DESIGN/LAYOUT PROBLEMS**


Avoid ground loops or running digital and analog traces parallel to each other (side-by-side) on the same PCB layer. When traces must cross over each other, do so at 90 degrees. Running digital and analog traces at 90 degrees to each other from the top to the bottom side as much as possible will minimize capacitive noise coupling and crosstalk.




	laterials LM48821供应语 Part Description	Value	Tolerance	Rating	Package Type	Manufacturer	Manufacturer's Part Number	AN-1589
C1–C4	TACmicrochip tantalum capacitor	0.47µF	±20%	10V	0402	AVX	TACK474M010PTA	0.001
C5, C9	Multilayer Ceramic Capacitor	0.1µF	±10%	6.3V	0201	ток	C0603X5R1A104M	
C6, C8	Multilayer Ceramic Capacitor	4.7µF	±20%	6.3V	0603	TDK	C1608X5R1A475M	
C7	Multilayer Ceramic Capacitor	4.7µF	±20%	10V	0805	TDK	C2012X5R1A475M	10
J1	Headphone Jack					(Ht In	W.DZS	5.00
J2–J6	2-pin header, 100mil lead pitch			30	- (	ZEIE	- 10 m	
J8	5-pin header, 100mil lead pitch							
JU1	3-pin header, 100mil lead pitch	WW	W.S.					
U1	LM48821Direct Coupled Tru- GND, Ultra Low Noise, 80mW Differential Inputs Stereo Headphone Amplifier with I <sup>2</sup> C Volume Control		子市 W.DZSI			National Semiconductor Corp	LM48821TL	2.001
	Volume Control		3 mil	ΣM		维库	www.bzs	3
								30.00
We	Ser.			5			www.national	com




zsc.com





con



# Appendix A LM48821 I<sup>2</sup>C Control Register 查询LM48821供应商 Table B1 shows the actions that are implemented by manipulating the bits within the internal I<sup>2</sup>C control register.

	D7	D6	D5	D4	D3	D2	D1	DO
I <sup>2</sup> C Address	1	1	1	0	1	1	0	0
Control Register	V4	V3	V2	V1	V0	MUTE	LEFT ENABLE	RIGHT ENABLE

Kpd

zsc.com

#### Table A1. LM48821 I<sup>2</sup>C Control Register Addressing and Data Format Chart

# Appendix B Volume Control Settings Binary Values

The minimum volume setting is set to -76dB when 00000 is loaded into the volume control register. Incrementing the vol-

ume control register in binary fashion increases the volume control setting, reaching full scale at 11111. Table B1 shows the value of the gain for each of the 32 binary volume control settings.

www.national.com

com

ZSC	B0	B1	B2	B3	B4	Gain
	1	1	I o1\(6) }	1	1	18
	0	1	1	LaM	1	17
	1	0	1	ZSC.		16
	0	0	1	1	WIW W	15
	1	1	0	1	1	14
	0	1	0	1	1	13
51	1	0	0	1	1	12
750	0	0	0	1	1	10
120	WWW.DL-	1	1	0	1	8
	0	1	1/30 1	0	1	6
	1	0	1	0	1 1	4
	0	0	1	0	1	2
	1	1	0	0		0
	0	1	0	0	1	-2
	1	0	0	0	1	-4
578	0	0 💎	0	0	1	-6
750	1 .79	1	1	1	0	-8
1.0	W VO	1	1	1	0	-10
	1	0	1.82	1	0	-12
	0	0	1	1	0	-14
	1	1	0	750.00M	0	-16
	0	1	0	1	0	-18
	1	0	0	1	0	-21
	0	0	0	1	0	-24
51	1	1	1	0	0	-27
V	0	1	1	0	0	-30
1250	WW.DZS	0	1	0	0	-34
	0	0	1	0	0	-38
	1	1	0	0	0	-44
	0	1	0	0.0 M	0	-52
	1	0	0	2500	0	-62
	0	0	0	0	0	-76





O

f.dzsc.com

<b>on History</b> 洵LM48821供应商 <sub>Rev</sub>	Date	Description	
1.0	05/14/07	Initial release.	-12
			ZSC.C
	13		tional.com

▲ 当此48821供应商
Notes
● 日本の「日本の」」

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED IN CONNECTION WITH NATIONAL SEMICONDUCTOR CORPORATION ("NATIONAL") PRODUCTS. NATIONAL MAKES NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THE ACCURACY OR COMPLETENESS OF THE CONTENTS OF THIS PUBLICATION AND RESERVES THE RIGHT TO MAKE CHANGES TO SPECIFICATIONS AND PRODUCT DESCRIPTIONS AT ANY TIME WITHOUT NOTICE. NO LICENSE, WHETHER EXPRESS, IMPLIED, ARISING BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT.

TESTING AND OTHER QUALITY CONTROLS ARE USED TO THE EXTENT NATIONAL DEEMS NECESSARY TO SUPPORT NATIONAL'S PRODUCT WARRANTY. EXCEPT WHERE MANDATED BY GOVERNMENT REQUIREMENTS, TESTING OF ALL PARAMETERS OF EACH PRODUCT IS NOT NECESSARILY PERFORMED. NATIONAL ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR BUYER PRODUCT DESIGN. BUYERS ARE RESPONSIBLE FOR THEIR PRODUCTS AND APPLICATIONS USING NATIONAL COMPONENTS. PRIOR TO USING OR DISTRIBUTING ANY PRODUCTS THAT INCLUDE NATIONAL COMPONENTS, BUYERS SHOULD PROVIDE ADEQUATE DESIGN, TESTING AND OPERATING SAFEGUARDS.

EXCEPT AS PROVIDED IN NATIONAL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, NATIONAL ASSUMES NO LIABILITY WHATSOEVER, AND NATIONAL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY RELATING TO THE SALE AND/OR USE OF NATIONAL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

#### LIFE SUPPORT POLICY

NATIONAL'S PRODUCTS ARE NOT AUTHORIZED FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE EXPRESS PRIOR WRITTEN APPROVAL OF THE CHIEF EXECUTIVE OFFICER AND GENERAL COUNSEL OF NATIONAL SEMICONDUCTOR CORPORATION. As used herein:

Life support devices or systems are devices which (a) are intended for surgical implant into the body, or (b) support or sustain life and whose failure to perform when properly used in accordance with instructions for use provided in the labeling can be reasonably expected to result in a significant injury to the user. A critical component is any component in a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system or to affect its safety or effectiveness.

National Semiconductor and the National Semiconductor logo are registered trademarks of National Semiconductor Corporation. All other brand or product names may be trademarks or registered trademarks of their respective holders.

Copyright© 2007 National Semiconductor Corporation

For the most current product information visit us at www.national.com



AN-1589

National Semiconductor Americas Customer Support Center Email: new.feedback@nsc.com Tel: 1-800-272-9959 National Semiconductor Europe Customer Support Center Fax: +49 (0) 180-530-85-86 Email: europe.support@nsc.com Deutsch Tel: +49 (0) 69 9508 6208 English Tel: +49 (0) 870 24 0 2171 Français Tel: +33 (0) 1 41 91 8790 National Semiconductor Asia Pacific Customer Support Center Email: ap.support@nsc.com National Semiconductor Japan Customer Support Center Fax: 81-3-5639-7507 Email: jpn.feedback@nsc.com Tel: 81-3-5639-7560

00

www.national.com