MOS FET Power Amplifier Module for Mobile Phone

HITACHI

ADE-208-461 (Z) 1st Edition July 1, 1996

Application

PF0031: For NMT900 890 to 925 MHz

Features

• High stability: Load VSWR ≈ 20:1

WWW.DZSC.COM Low power control current: 400 µA


Thin package: 5 mm t

Pin Arrangement





Internal Diagram and External Circuit




Absolute Maximum Ratings (Tc = 25°C)

Item	Symbol	Rating	Unit
Supply voltage	V _{DD}	17	V
Supply current	I _{DD}	3	Α
APC voltage	V _{APC}	8	V
Input power	Pin	20	mW
Operating case temperature	Tc (op)	-30 to +100	°C
Storage temperature	Tstg	-40 to +110	°C

Electrical Characteristics (Tc = 25°C)


Item	Symbol	Min	Тур	Max	Unit	Test Condition
Drain cutoff current	I _{DS}	_	_	500	μΑ	$V_{DD} = 17 \text{ V}, V_{APC} = 0 \text{ V}, Rg = R_{L} = 50 \Omega$
Total efficiency	$\eta_{\scriptscriptstyle T}$	35	40	_	%	Pin = 2 mW, $V_{DD} = 12.5 \text{ V}$,
2nd harmonic distortion	2nd H.D.	_	-50	-30	dB	Pout = 6 W (at APC controlled)
3rd harmonic distortion	3rd H.D.	_	-50	-30	dB	$R_L = Rg = 50 \Omega$
Input VSWR	VSWR (in)	_	1.5	3	_	_
Output VSWR	VSWR (out)	_	1.5	_	_	_
Stability	_	No parasitic oscillation —		_	Pin = 2 mW, V_{DD} = 12.5 V, Pout = 6 W (at APC controlled), R_L = Rg = 50 Ω , Output VSWR = 20:1 All phases, t = 20sec	

Test System Diagram



Test Fixture Pattern

Unit: mm




Mechanical Characteristics


Item	Conditions	Spec 4 to 6 kg•cm	
Torque for screw up the heatsink flange	M3 Screw Bolts		
Warp size of the heatsink flange: S		S = 0 +0.3/- 0 mm	


Note for Use


- Unevenness and distortion at the surface of the heatsink attached module should be less than 0.05 mm.
- It should not be existed any dust between module and heatsink.
- MODULE should be separated from PCB less than 1.5 mm.
- Soldering temperature and soldering time should be less than 230°C, 10 sec. (Soldering position spaced from the root point of the lead frame: 2 mm)
- Recommendation of thermal joint compounds is TYPE G746.
 - (Manufacturer: Shin-Etsu Chemical, Co., Ltd.)
- To protect devices from electro-static damage, soldering iron, measuring-equipment and human body etc. should be grounded.
- Torque for screw up the heatsink flange should be 4 to 6 kg · cm with M3 screw bolts.
- Don't solder the flange directly.
- It should make the lead frame as straight as possible.
- The module should be screwed up before lead soldering.
- It should not be given mechanical and thermal stress to lead and flange of the module.
- When the external parts (Isolator, Duplexer, etc.) of the module are changed, the electrical characteristics should be evaluated enough.
- Don't washing the module except lead pins.
- To get good stability, ground impedance between the module GND flange and PCB GND pattern should be designed as low as possible.


Characteristics Curve














Package Dimensions

