

# HT9290A/B One-Key Dialer

**Features**

- Operating voltage: 2.0V~5.5V
- Low standby current
- 22-digit memory at max.
- Pause time selectable by programming (0.3/0.9 sec)


Patent Number: 113235(R.O.C.), 5424740(U.S.A.)

- Phone number programmable/readable
- Pause time for HT9290A can be accumulated
- 3.58MHz crystal or ceramic resonator
- Two kinds of nonretriggerable trigger functions (local/long distance call)

**General Description**

The HT9290A/B are programmable one-key tone dialer. It provides a station number with two trigger pins for long distance (HT9290A) and local (HT9290B) call dialing. The DTMF


pin will output the tone signal if any of the two trigger pins is actuated. A phone number of 22-digit memory at maximum can be programmed through the DATA and CLOCK pins.

**Pin Assignment****Block Diagram**

### Pad Description

<b>Pad No.</b>	<b>Pad Name</b>	<b>I/O</b>	<b>Internal Connection</b>	<b>Description</b>
1	DATA	I/O	CMOS IN/OUT Pull-High	Data input or output (interface to $\mu$ C)
2	CLOCK	I/O	CMOS IN/OUT Pull-High	Clock input or output (interface to $\mu$ C)
3	X1	I	OSCILLATOR	The system oscillator consists of an inverter, a bias resistor and the necessary load capacitor on chip. Connecting a standard 3.579545MHz crystal or ceramic resonator to the X1 and X2 terminals can implement the oscillator function. The oscillator is turned off in the standby mode, and will be actuated whenever the $\overline{\text{TG1}}/\overline{\text{TG2}}$ entry is detected.
4	X2	O		
5	VDD	I	—	Positive power supply, 2V~5.5V for normal operation
6	$\overline{\text{TG2}}$	I	CMOS IN Pull-High	Trigger for local call, active low
7	$\overline{\text{TG1}}$	I	CMOS IN Pull-High	Trigger for long distance call, active low
8	VSS	I	—	Negative power supply
9	DTMF	O	CMOS OUT	Output terminal of tone signal

### Approximate internal connection circuits



### Absolute Maximum Ratings\*

Supply Voltage .....	-0.3V to 6V	Storage Temperature .....	-50°C to 125°C
Input Voltage .....	V <sub>SS</sub> -0.3 to V <sub>DD</sub> +0.3V	Operating Temperature .....	-20°C to 75°C

\*Note: Stresses above those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only. Functional operation of this device at these or any other conditions above those indicated in the operational sections of this specification is not implied and exposure to absolute maximum rating conditions for extended periods may affect device reliability.

**Electrical Characteristics**

(Ta=25°C)

<b>Symbol</b>	<b>Parameter</b>	<b>Test Conditions</b>		<b>Min.</b>	<b>Typ.</b>	<b>Max.</b>	<b>Unit</b>
		<b>V<sub>DD</sub></b>	<b>Conditions</b>				
V <sub>DD</sub>	Operation Voltage	—	—	2	—	5.5	V
I <sub>DD</sub>	Operation Current	2.5V	—	—	0.6	2	mA
V <sub>IL</sub>	“Low” Input Voltage	2.5V	—	V <sub>SS</sub>	—	0.2V <sub>DD</sub>	V
V <sub>IH</sub>	“High” Input Voltage	2.5V	—	0.8V <sub>DD</sub>	—	V <sub>DD</sub>	V
I <sub>STB</sub>	Standby Current	2.5V	Oscillator stop	—	—	1	μA
R <sub>TG</sub>	Pull-High Resistance (TG1, TG2)	2.5V	V( $\overline{\text{TG1}}$ , $\overline{\text{TG2}}$ )=0V	—	300	—	kΩ
R <sub>DAT</sub>	Pull-High Resistance (DATA)	2.5V	V <sub>DATA</sub> =0V	—	60	—	kΩ
R <sub>CLOCK</sub>	Pull-High Resistance (CLOCK)	2.5V	V <sub>CLOCK</sub> =0V	—	60	—	kΩ
V <sub>MR</sub>	Memory Retention Voltage	—	—	1	—	5.5	V
I <sub>MR</sub>	Memory Retention Current	2V	—	—	0.2	0.5	μA
V <sub>TDC</sub>	DTMF Output DC Level	2V~5.5V	DTMF output	0.45V <sub>DD</sub>	—	0.75V <sub>DD</sub>	V
I <sub>TOL</sub>	DTMF Sink Current	2.5V	V <sub>DTMF</sub> =0.5V	0.1	—	—	mA
V <sub>TAC</sub>	DTMF Output AC Level	2.5V	Row group, R <sub>L</sub> =5kΩ	0.12	0.15	0.18	V <sub>rms</sub>
R <sub>L</sub>	DTMF Output Load	2.5V	THD ≤ -23 dB	5	—	—	kΩ
ACR	Column Pre-emphasis	2.5V	Row group=0dB	1	2	3	dB
THD	Tone Signal Distortion	2.5V	R <sub>L</sub> =5kΩ	—	-30	-23	dB
FOSC	System Frequency	—	Crystal=3.5795MHz	3.5759	3.5795	3.5831	MHz

**A.C. Electrical Characteristic**

(FOSC=3.5795MHz, Ta=25°C)

<b>Symbol</b>	<b>Parameter</b>	<b>Test Conditions</b>		<b>Min.</b>	<b>Typ.</b>	<b>Max.</b>	<b>Unit</b>
		<b>V<sub>DD</sub></b>	<b>Conditions</b>				
T <sub>TD</sub>	Tone Duration	2V~5.5V	DTMF output	—	100	—	ms
T <sub>ITP</sub>	Inter-tone Pause	2V~5.5V	DTMF output	—	106	—	ms
T <sub>P1</sub>	Tone Pause Time For P1	2V~5.5V	—	—	0.3	—	s
T <sub>P2</sub>	Tone Pause Time For P2	2V~5.5V	—	—	0.9	—	s
t <sub>C</sub>	Clock Period	5V	—	0.2	—	2	ms
t <sub>SACC</sub>	Store Accept Time	5V	—	0.6	—	2	ms
t <sub>IDP</sub>	Inter-digit-pause Time	5V	—	0.6	—	2	ms
t <sub>RACC</sub>	Read Accept Time	5V	—	—	—	15	ms
t <sub>CKR</sub>	Clock Rising Time	5V	—	—	—	100	ns
t <sub>CKF</sub>	Clock Falling Time	5V	—	—	—	100	ns
t <sub>CKL</sub>	Clock Low Time	5V	—	0.1	—	—	ms
t <sub>CKH</sub>	Clock High Time	5V	—	0.1	—	—	ms

$$\text{THD (Distortion) (dB)} = 20 \log \left( \sqrt{\text{V1}^2 + \text{V2}^2 + \dots + \text{Vn}^2} / \sqrt{\text{Vi}^2 + \text{Vh}^2} \right)$$

Vi,Vh: Row group and Column group signals

V1,V2,...,Vn: Harmonic signals (BW=300Hz~3500Hz)

## Functional Description

The HT9290A/B is a one-key tone dialer. A station number with 22 digits at maximum can be programmed. The HT9290A is used for long distance calls while the HT9290B is used for local calls. The phone number can be easily programmed through HOLTEK's programming kit (refer to Figure 1).




Figure 1. Programming kit wiring diagram

Every digit of the phone number consists of a 5-bit data. It receives data at the rising edge of the CLOCK (refer to Figure 2). The relation of the digital codes and tone output frequency are shown in Table 1.

### Programming timing diagram




Figure 2. Programming timing

**Table 1: Digits vs. input data vs. tone output frequency**

<b>Digit</b>	<b>D4</b>	<b>D3</b>	<b>D2</b>	<b>D1</b>	<b>D0</b>	<b>Tone Output Frequency (Hz)</b>
1	0	0	0	0	1	697+1209
2	0	0	0	1	0	697+1336
3	0	0	0	1	1	697+1477
4	0	0	1	0	0	770+1209
5	0	0	1	0	1	770+1336
6	0	0	1	1	0	770+1477
7	0	0	1	1	1	852+1209
8	0	1	0	0	0	852+1336
9	0	1	0	0	1	852+1477
0	0	1	0	1	0	941+1336
*	0	1	1	0	1	941+1209
#	0	1	1	0	0	941+1477
A	1	0	0	0	0	697+1633
B	1	0	0	0	1	770+1633
C	1	0	0	1	0	852+1633
D	1	0	0	1	1	941+1633
P1	0	1	0	1	1	—
P2	0	1	1	1	0	—
WRITE	1	1	0	1	0	—
READ	1	1	0	0	0	—
SEND	0	0	0	0	0	—

When the HT9290A/B receives the WRITE code (11010), the phone number is stored from MSB to LSB, and the SEND (00000) code is added at the end of the phone number until 22 digits are reached.

When the HT9290A/B receives the serial data (11000) from the programming kit, the code of the phone number is sent back to the kit from MSB to LSB for verification.

#### Using the programming kit (Figure 1.)

- WRITE

Store 035-784888 into the HT9292A/B.  
Press these keys into the programming kit:  
F 035 P (P1 or P2) 784888 SEND

- READ

Press these keys into the programming kit: F  
READ

- Dialing


Memory content: 035 P1 (or P2) 784888  
TG1 trigger: 035 T<sub>P1</sub> (or T<sub>P2</sub>) 784888  
TG2 trigger: 784888

The TG1 and TG2 are trigger pins. If TG1 is "H" to "L", it sends a long distance call. If TG2 is "H" to "L", it sends a local call. The telephone number is dialed out from the DTMF pin.


Note: The stored number will be lost if the power supply is removed

## Application Circuits

### Long distance call



### Local call



Note: (a) X'TAL = 3.579545MHz crystal  
 $C_1 = C_2 \approx 20\text{pF}$

(b) X'TAL = 3.58MHz ceramic resonator  
 $C_1 = C_2 \approx 39\text{pF}$